Name: Md.Abdullah

**ID**: IT-17015

Lab report no: 04

Name of the Lab report : Echo protocol

## **Objectives:**

- ✓ Learn eco TCP server
- ✓ Learn eco TCP client
- ✓ Learn eco UDP server
- ✓ Learn eco UDP client

## Theory:

Python's socket module provides an interface to the Berkeley sockets API. The primary socket API functions and methods in this module are:

- socket()
- bind()
- listen()
- accept()
- connect()
- connect\_ex()
- send()
- recv()
- close()

## **Echo TCP server program:**

```
import socket
```

```
HOST = '127.0.0.1'

PORT = 65432

with socket.socket(socket.AF_INET, socket.SOCK_STREAM) as s:
    print("Echo tcp server created succesfully")
    s.bind((HOST, PORT))
    s.listen()
    conn, addr = s.accept()
    with conn:
        print('Got connection from', addr)
        while True:
        data = conn.recv(1024)
```

```
if not data:
    break
conn.sendall(data)
```

#### **Echo TCP clients:**


```
import socket
```

```
HOST = '127.0.0.1' # The server's hostname or IP address
PORT = 65432  # The port used by the server


with socket.socket(socket.AF_INET, socket.SOCK_STREAM) as s:
    s.connect((HOST, PORT))
    s.sendall(b'Hello, world')
    data = s.recv(1024)

print('Received', repr(data))
```

## Running the server result:



# **Running the Client result:**




### **Echo UDP server:**


```
import socket
import sys
# Create a TCP/IP socket
sock = socket.socket(socket.AF INET, socket.SOCK DGRAM)
# Bind the socket to the port
server_address = ('localhost', 10000)
print('starting up on %s port %s' % server address)
sock.bind(server address)
while True:
  print('\nwaiting to receive message')
  data, address = sock.recvfrom(4096)
  print('received %s bytes from %s' % (len(data), address))
  print(data)
  if data:
    sent = sock.sendto(data, address)
    print('sent %s bytes back to %s' % (sent, address))
Echo UDP client:
import socket
import sys
# Create a UDP socket
sock = socket.socket(socket.AF INET, socket.SOCK DGRAM)
server address = ('localhost', 10000)
message = 'This is the message. It will be repeated.'
try:
  # Send data
  print('sending "%s"' % message)
  sent = sock.sendto(message.encode('utf-8'), server address)
  # Receive response
  print('waiting to receive')
  data, server = sock.recvfrom(4096)
```

```
print('received "%s"' % data)
finally:
  print( 'closing socket')
  sock.close()
```

#### **Running the server result:**



## **Running the client result:**



#### Discussion:

I can successfully run all the program of eco tcp server.py , eco tcp client.py ,echo udp server.py ,echo udp client.py